



How to unblock an Iridium SIM Card installed in Motorola 9500 or 9505 handsets

1. Switch on the Telephone
2. Using the handset keypad enter the following sequence * * 0 5 *
3. Enter the PUK 1 code from the SIM CARD information sheet
4. Press OK
5. You will be prompted to enter a new PIN Code. Choose a 4 digit number, different to the original PIN number
6. Repeat the entry of this number when prompted.
7. The LCD display will now show "completed"

